

Parts list and mounting instruction

Best No.: 7276 HO DGX VT 750 C ABS Best No.: 7277 HO DGX VT 750 C ABS, black **Article:** Protection Guard **Article:** Protection Guard, black

Fits for: VT 750 C Shadow with ABS (RC 50) and VT 750 C Shadow Spirit (RC 53) with ABS, VT 750 C4 Shadow (RC 50), VT 750 C7 Shadow Spirit (RC 53) without ABS, VT 750 C Shadow Black Spirit

1 Protection Guard

1 x Parts list and mounting instruction

Mounting parts on top:

1x Connection Strap

Connection Strap on motorcycle: 1 x Hexagon socket head cap screw 1 x Washer 2 x Hexagon socket button head screw 4 x Distance washer	DIN 912 DIN 9021 ISO 7380 DIN 7349	M 6 x 35 mm M 6 M 5 x 30 mm M 6
Protection Guard on connection strap:		
2 x Hexagon Screw	DIN 933	M 8 x 20 mm
2 x Hexagon nut	DIN 985	M 8
Mounting parts below left: 1 x Hexagon Screw 1 x Washer 1 x Distance tube	DIN 960 DIN 125	M 10 x 1.25 x 40 mm M 10 18 x 3.75 x 10 mm
Mounting parts below right: 1 x Hexagon Screw 2 x Washer 1 x Hexagon nut 1 x Distance tube	DIN 931 DIN 125 DIN 985	M 10 x 110 mm M 10 M 10 18 x 3.75 x 10 mm

2 x Ribbed inserts for tube ends

SRL 38



Picture 7375

	Erstellt	Geändert	Geprüft Entwicklung	Geprüft Verkauf	Freigabe
Datum/Name	2010-10-26 PU	2011-05-10 JF		2011-05-10 PU	2011-05-10 JF



Mounting instruction:

- Remove the horn.
- Mount the connection strap with the listeded mounting parts.
- On the outer connection points of the connection strap, in each case 2 Distance washers are mounted between strap and Frame.
- Mount the Protection Guard on the connection points loose with the listeded mounting parts.
- Protection Guards aim and tighten all screws.
- In order to avoid a damage of the fender during the assembly it is absolutely necessary to push the Protection Guard as far as possible on the Frame. In addition, solve all Fender screws and press the guard as far as possible down. Afterwards aim and tighten all screws.
- The Distance tubes on the below connection points are mounted between Frame and Protection Guard.
- Mount the Horn.



Picture 7276+77_M_OL



Picture 7276+77_M_OM



Picture 7276+77_M_OR

Care and servicing:

To reach a long live span of our chromium-plated articles they should be cleaned regulary and be treated with customary chrome care means.

With powder coated articles a regular cleaning is important. Damages (e.g. by rockfall) can be mended with colour.

By both versions we recommend about the winter the spraying or rubbing with corrosion protection oil or silicone.

All fixing bolts must be checked at regular intervals (max. 6 months).

We wish you a lot of joy and accident-free journey with our motorcycle accessories.